



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž



Skoda Superb II Kombi (2008-2015)

SUP2K BEZ KL

SOLARRIDE Zestawki osłony przeciwsłoneczne Skoda Superb II Kombi (2008-2015) BEZ KLAPY 2lg



6 x



2 x



