



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž



PEUGEOT 308 III SW (2021->)

308K III DR


SOLARRIDE ZASŁONKI DO Peugeot 308 III / Peugeot e-308 KOMBI dr 1kg



5 904423 655012 >



Videoinstrukcja - zeskanuj kod QR
Videoinstruction - scan the QR code
Video návod - naskenujte QR kód
Instruction vidéo - scanner le code QR
Video de instrucciones: escanee el código QR
Videoanleitung - Scannen Sie den QR-Code
Video de instrucciones: escanee el código QR
Instruções em vídeo - digitalizar o código QR
Istruzioni video - scansione del codice QR



4 x



