



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




VW Volkswagen Golf 4 IV 3DR
(1997-2006)

G40 KPL

SOLARRIDE Zakonni oslony przeciwsloneczne VW Volkswagen Golf 4 IV 3DR (1997-2006) KPL 3lg



5 904035 793065 >



2x



