



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Ford C-Max II (2010-2019)

C MAX 2 KPL

SOLARRIDE. Załoznik / modelis / osłony przeciwsłoneczne SolarRide Ford C-Max II (2010-2019) KPL 3kg



5 904035 792921 >



7x



