



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Ford Focus II Hatchback 5dr (2004-2011)

FOK2HB 5DR BEZ KL


SOLARRIDE Zaklady, ostatky przeciwkondensacyjne Ford Focus II Hatchback 5 Drzwi (2004-2011) bez kl. 2lg



5 904035 797513 >



6 x



4 x





Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž



