



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Mercedes-Benz C-Class W203 Sedan
(2001-2007)

W203S DR

SOLARRIDE žalovniki, izdelani posebej za Mercedes-Benz W203 Sedan C-Klasa (1999-2007) 1lg.



5 904035 791535 >



6 x







Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž

